

## **GSM TELEPHONE SGH-P100**

# SERVICE Manual

#### **GSM TELEPHONE**



#### **CONTENTS**

- Specification 1.
- 2. Circuit Description
- Exploded Views and Parts List 3.
- **Electrical Parts List** 4.
- **Block Diagrams**
- 6. PCB Diagrams
- Flow Chart of Troubleshooting



This Service Manual is a property of Samsung Electronics Co.,Ltd.

Any unauthorized use of Manual can be punished under applicable International and/or domestic law.

Samsung Electronics Co.,Ltd. August. 2003 Printed in Korea.

Code No.: GH68-03791A

BASIC.

## 1. SGH-P100 Specification

#### 1. GSM General Specification

	GSM900 Phase 1	EGSM 900 Phase 2	DCS1800 Phase 1	PCS1900
Freq. Band[MHz] Uplink/Downlink	890~915 935~960	880~915 925~960	1710~1785 1805~1880	1850~1910 1930~1990
ARFCN range	1~124	0~124 & 975~1023	512~885	512~810
Tx/Rx spacing	45MHz	45MHz	95MHz	80MHz
Mod. Bit rate/ Bit Period	270.833kbps 3.692us	270.833kbps 3.692us	270.833kbps 3.692us	270.833kbps 3.692us
Time Slot Period/Frame Period	576.9us 4.615ms	576.9us 4.615ms	576.9us 4.615ms	576.9us 4.615ms
Modulation	0.3GMSK	0.3GMSK	0.3GMSK	0.3GMSK
MS Power	33dBm~13dBm	33dBm~5dBm	30dBm~0dBm	30dBm~0dBm
Power Class	5pcl ~ 15pcl	5pcl ~ 19pcl	0pcl ~ 15pcl	0pcl ~ 15pcl
Sensitivity	-102dBm	-102dBm	-100dBm	-100dBm
TDMA Mux	8	8	8	8
Cell Radius	35Km	35Km	2Km	-

### 2. GSM TX power class

TX Power control level	GSM900
5	33 ±2 dBm
6	31 ±2 dBm
7	29 ±2 dBm
8	27 ±2 dBm
9	25 ±2 dBm
10	23 ±2 dBm
11	21 ±2 dBm
12	19 <b>±</b> 2 dBm
13	17 <b>±</b> 2 dBm
14	15 ±2 dBm
15	13 <b>±</b> 2 dBm
16	11 ±3 dBm
17	9 ±3dBm
18	7 ±3 dBm
19	5 ±3 dBm

TX Power control level	DCS1800
0	30±2 dBm
1	28±3 dBm
2	26±3 dBm
3	24±3 dBm
4	22±3 dBm
5	20±3 dBm
6	18±3 dBm
7	16±3 dBm
8	14±3 dBm
9	12 ±4 dBm
10	10±4 dBm
11	8 ±4dBm
12	6±4 dBm
13	4 ±4 dBm
14	2±5 dBm
15	0±5 dBm

TX Power control level	PCS1900
0	30 ±2 dBm
1	28 ±3 dBm
2	26±3 dBm
3	24 ±3 dBm
4	22 ±3 dBm
5	20±3 dBm
6	18±3 dBm
7	16±3 dBm
8	14 ±3 dBm
9	12 <b>±</b> 4 dBm
10	10±4 dBm
11	8 ±4dBm
12	6 ±4 dBm
13	4 ±4 dBm
14	2 ±5 dBm
15	0 ±5 dBm

## 2. SGH-P100 Circuit Description

#### 1. SGH-P100 RF Circuit Description

#### 1) RX PART

- 1. ASM(U1001) Switching Tx, Rx path for GSM900, DCS1800 and PCS1900 by logic controlling.
- 2. ASM Control Logic (U701, U702, U703) Truth Table

	VC1	VC2	VC3
GSM Tx Mode	Н	L	L
DCS / PCS Tx Mode	L	Н	L
PCS Rx Mode	L	L	Н
GSM / DCS Rx Mode	L	L	L

#### 3. FILTER

To convert Electromagnetic Field Wave to Acoustic Wave and then pass the specific frequency band.

- GSM FILTER (C1003,C1004,L1001) For filtering the frequency band between 925 ~ 960 MHz
- DCS FILTER (C1005,C1006,L1002) For filtering the frequency band 1805 and 1880 MHz.
- PCS SAW FILTER (F1003) For filtering the frequency band between 1930 and 1990 MHz

#### 4. TC-VCXO (OSC901)

To generate the 13MHz reference clock to drive the logic and RF.

After additional process, the reference clock applies to the U900 Rx IQ demodulator and Tx IQ modulator.

The oscillator for RX IQ demodulator and Tx modulator are controlled by serial data to select channel and use fast lock mode for GPRS high class operation.

#### 5. SI 4205 (U900)

This chip integrates three differential-input LNAs.

The GSM input supports the E-GSM, DCS input supports the DCS1800, PCS input supports the PCS1900. The LNA inputs are matched to the 150 ohm differential output SAW filters through external LC matching network.

Image-reject mixer downconverts the RF signal to a 100 KHz intermediate frequency(IF) with the RFLO from frequency synthesizer. The RFLO frequency is between 1737.8 ~ 1989.9 MHz.

The Mixer output is amplified with an analog programmable gain amplifier(PGA), which is controlled by AGAIN. The quadrature IF signal is digitized with high resolution A/D converts (ADC).

Also, this chip down-converts the ADC output to baseband with a digital 100 KHz quadrature LO signal. Digital decimation and IIR filters perform channel selection to remove blocking and reference interface signals.

After channel selection, the digital output is scaled with a digital PGA, which is controlled with the DGAIN. DACs drive a differential analog signal onto the RXIP, RXIN, RXQP, RXQN pins to interface to standard analog-input baseband IC.

#### 2) TX PART

Baseband IQ signal fed into offset PLL, this function is included inside of U900 chip.

SI4205 chip generates modulator signal which power level is about 1.5dBm and fed into Power Amplifier(U1000).

The PA output power and power ramping are well controlled by Auto Power Control circuit. We use offset PLL below

	200kHz offset 30 kHz bandwidth	GSM	-35dBc
		DCS	-35dBc
		PCS	-35dBc
Modulation Spectrum	400kHz offset 30 kHz bandwidth	GSM	-66dBc
		DCS	-65dBc
		PCS	-66dBc
	600kHz ~ 1.8MHz offset 30 kHz bandwidth	GSM	-75dBc
		DCS	-68dBc
		PCS	-75dBc

#### 2. Baseband Circuit description of SGH-P100

#### 1. PSC2006

#### 1.1. Power Management

Seven low-dropout regulators designed specifically for GSM applications power the terminal and help ensure optimal system performance and long battery life. A programmable boost converter provides support for 1.8V, 3.0V, and 5.0V SIMs, while a self-resetting, electronically fused switch supplies power to external accessories. Ancillary support functions, such as an LED driver and two call-alert drivers, aid in reducing both board area and system complexity. A three-wire serial interface unit(SIU) provides access to control and configuration registers. This interface gives a microprocessor full control of the PSC2006 and enables system designers to maximize both standby and talk times. Supervisory functions. including a reset generator, an input voltage monitor, and a thermal monitor, support reliable system design. These functions work together to ensure proper system behavior during start-up or in the event of a fault condition(low microprocessor voltage, insufficient battery energy, or excessive die temperature).

#### 1.2. Battery Charge Management

A battery charge management block provides fast, efficient charging of a single-cell Li-ion battery. Used in conjunction with a current-limited voltage source and an external PMOS pass transistor, this block safely conditions near-dead cells and provides the option of having fast-charge and top-off controlled internally or by the system's microprocessor.

#### 1.3. Backlight LED Driver

The backlight LED driver is a low-side, programmable current source designed to control the brightness of the keyboard and LCD illumination. The driver is enabled by EN\_LED, and its current setting is determined by LED[0:2]. Provided EN\_LED is '1', the driver can be programmed to sink from 12.5mA to 100mA in 12.5mA steps. LED\_DRV is capable of sinking 100mA at a worst-case maximum output voltage of 0.6V. For efficient use, the LEDs is connected between the battery and the LED\_DRV output.

#### This Document can not be used without Samsung's authorization

#### 1.4. Vibrator Motor Dirver

The vibrator motor driver is a low-side, programmable voltage source designed to drive a small dc motor that silently alerts the user of an incoming call. The driver is enabled by EN\_VIB, and its voltage setting is determined by VIB[0:2]. Provided EN\_VIB is a logic 1, the driver can be programmed to maintain a motor voltage of 1.1V to 2.5V in 20mV steps and while sinking up to 100mA. For efficient use, the vibrator motor should be connected between the main battery and the VIB DRV output.

#### 2. Connector

#### 2-1. LCD Connector

LCD is consisted of main LCD(color 65K STN LCD) and small LCD(4-gray LCD). Chip select signals of EMI part in the trident, CLCD\_EN\_FO and GLCD\_EN\_FO, can enable Each LCD. LED\_EN\_FO signal enables white LED of main LCD and EL\_EN\_FO signal enables EL of small LCD. These two signals are from IO part of the DSP in the trident. RST signal from 2006 initiates the initial process of the LCD.

16-bit data lines(D(0)\_FO~D(15)\_FO) transfers data and commands to LCD through emi\_filter. Data and commands use A(2)\_FO signal. If this signal is high, Inputs to LCD are commands. If it is low, Inputs to LCD are data. The signal which informs the input or output state to LCD, is required. But this system is not necessary this signal. So CP\_WEN\_FO signal is used to write data or commands to LCD. Power signals for LCD are V\_bat and V\_ccd. SPK1P and SPK1N from CSP1093 are used for audio speaker. And VIB\_EN\_FO from enables the motor.

#### 2-2. JTAG Connector

Trident has two JTAG ports which are for ARM core and DSP core(DSP16000). So this system has two port connector for these ports. Pins ' initials for ARM core are ' CP\_ ' and pins ' initials for DSP core are ' DSP\_ '. CP\_TDI and DSP\_TDI signal are used for input of data. CP\_TDO and DSP\_TDO signals are used for the output of the data. CP\_TCK and DSP\_TCK signals are used for clock because JTAG communication is a synchronous. CP\_TMS and DSP\_TMS signals are test mode signals. The difference between these is the RESET\_INT signal which is for ARM core RESET.

#### 2-3. IRDA

This system uses IRDA module, HSDL\_3201, HP 's. This has signals, IRDA\_EN(enable signal), IRDA\_RX(input data) and IRDA\_TX(output data). These signals are connected to PPI of trident. It uses two power signals. V\_ccd is used for circuit and V bat is used for LED.

#### 2-4. Keypad connector

This is consisted of key interface pins among PPI in the trident, KEY\_ROW[0~4] and KEY\_COL[0~4]. These signals compose the matrix. Result of matrix informs the key status to key interface in the trident. Some pins are connected to varistor for ESD protection. And power on/off key is seperated from the matrix. So power on/off signal is connected with PSC2006 to enable PSC2006. SVC\_GREEN, SVC\_RED and SVC\_BLUE are from OCTL of CSP1093. These signals decide the color of LED, service indicator. Eighteen key LED use the V\_bat supply voltage. These are connected to BACKLIGHT signal in the PSC2006. This signal enables LEDs with current control. FLIP\_SNS informs the status of folder (open or closed) to the trident. This uses the hall effect IC, A3210ELH. A magnet under main LCD enables A3210ELH which is on the key FPCB.

#### 3. IF connetor

It is 24-pin connector, and uses 18-pin at present. They are designed to use SDS, DEBUG, DLC-DETECT, JIG\_ON, VEXT, VTEST, VF, CF, VBAT and GND. They connected to power supply IC, microprocessor and signal processor IC.

#### 4. Audio

AOUTAP from CSP1093 is connected to the main speaker. AOUTAN is connected to the speaker via audio-amp. AOUTBN and AOUTBP are connected to the ear-mic speaker via ear-jack. MICIN and MICOUT are connected to the main MIC. And AUXIN and AUXOUT are connected to the Ear-mic.

YMU762MA3 is a LSI for portable telephone that is capable of playing high quality music by utilizing FM synthesizer and ADPCM decorder that are included in this device.

As a synthesis, YMU762MA3 is equipped 16 voices with differenttones. Since the device is capable of simultaneously generating up to synchronous with the play of the FM synthesizer, various sampled voices can be used as sound effects. Since the play data of YMU762MA3 are interpreted at anytime through FIFO, the length of the data(playing period) is not limited, so the device can flexiblysupport application such as incoming call melody music distribution service. The hardware sequencer built in this device allows playing of the complex music without giving excessive load to the CPU of the portable telephones. Moreover, the registers of the FM synthesizer can be operated directly for real time sound generation, allowing, for example, utilization of various sound effects when using the game software installed in the portable telephone.

YMU759 includes a speaker amplifier with high ripple removal rate whose maximum output is 550mW (SPVDD=3.6V). The device is also equipped with conventional function including a vibartor and a circuit for controlling LEDs synchronous with music.

For the headphone, it is provided with a stereophonic output terminal.

For the purpose of enabling YMU762MA3 to demonstarte its full capabilities, Yamaha purpose to use "SMAF:Synthetic music Mobile Application Format" as a data distribution format that is compatible with multimedia. Since the SMAF takes a structure that sets importance on the synchronization between sound and images, various contents can be written into it including incoming call melody with words that can be used for training karaoke, and commercial channel that combines texts, images and sounds, and others. The hardware sequencer of YMU762MA3 directly interprets and plays blocks relevant to systhesis (playing music and reproducing ADPCM with FM synthesizer) that are included in data distributed in SMAF.

#### 5. Memory

This system uses SHARP's memory, LRS1828. It is consisted of 128M bits flash memory and 32M bits SCRAM. It has 16 bit data line, D[0~15] which is connected to trident, LCD or CSP1093. It has 22 bit address lines, A[1~22]. They are connected too. CP\_CSROMEN and CO\_CSROM2EN signals, chip select signals in the trident enable two memories. They use 3 volt supply voltage, V\_ccd and 1.8 volt supply voltage, Vcc\_1.8a in the PSC2006. During wrting process, CP\_WEN is low and it enables writing process to flash memory and SRAM. During reading process, CP\_OEN is low and it output information which is located at the address from the trident in the flash memory or SRAM to data lines. Each chip select signals in the trident select memory among 2 flash memory and 2 SRAM. Reading or writing procedure is processed after CP\_WEN or CP\_OEN is enabled. Memories use FLASH\_RESET, which is buffered signal of RESET from PSC2006, for ESD protection. A[0] signal enables lower byte of SRAM and UPPER\_BYTE signal enables higher byte of SRAM.

#### 6. Trident

Trident is consisted of ARM core and DSP core. It has 20K\*16bits RAM 144K\*16bits ROM in the DSP. It has 4K\*32bits ROM and 2K\*32bits RAM in the ARM core. DSP is consisted of timer, one bit input/output unit(BIO), JTAG, EMI and HDS(Hardware Development System). ARM core is consisted of EMI, PIC(Programmable Interrupt Controller), reset/power/clock unit, DMA controller, TIC(Test Interface Controller), peripheral bridge, PPI, SSI(Synchronous Serial Interface), ACC(Asynchronous communications controllers), timer, ADC, RTC(Real-Time Clock) and keyboard interface. DSP\_AB[0~8], address lines of DSP core and DSP\_DB[0~15], data lines of DSP core are connected to CSP1093. A[0~20], address lines of ARM core and D[0~15], data lines of ARM core are connected to memory, LCD and YMU759. ICP(Interprocessor Communication Port) controls the communication between ARM core and DSP core. CSROMEN, CSRAMEN and CS1N to CS4N in the ARM core are connected to each memory. WEN and OEN control the process of memory. External IRQ(Interrupt ReQuest) signals from each units, such as, YMU, Ear-jack, Ear-mic and CSP1093, need the compatible process.

Some PPI pins has many special functions. CP\_KB[0~9] receive the status from key FPCB and are used for the communicatios using IRDA(IRDA\_RX/TX/EN) and data link cable(DEBUG\_DTR/RTS/TXD/RXD/CTS/DSR). And UP\_CS/SCLK/SDI, control signals for PSC2006 are outputted through PPI pins. It has signal port for charging(CHG\_DET, CHG\_STAT0), SIM\_RESET and FLIP\_SNS with which we knows open.closed status of folder. It has JTAG control pins(TDI/TDO/TCK) for ARM core and DSP core. It receives 13MHz clock in CKI pin from external TCXO and receives 32.768KHz clock from X1RTC. ADC(Analog to Digital Convertor) part receives the status of temperature, battery type and battery voltage. And control signals(DSP\_INT, DSP\_IO and DSP\_RWN) for DSP core are used. It enables main LCD and small LCD with DSP IP pins.

#### 7. CSP1093

CSP1093 integrates the timing and control functions for GSM 2+ mobile application with the ADC and DAC functions. The CSP1093 interfaces to the trident, via a 16-bit parallel interface. It serves as the interface that connects a DSP to the RF circuitry in a GSM 2+ mobile telephone. DSP can load 148 bits of burst data into CSP1093's internal register, and program CSP1093's event timing and control register with the exact time to send the burst. When the timing portion of the event timing and control register matches the internal quarter-bit counter and internal frame counter, the 148 bits in the internal register are GMSK modulated according to GSM 2+ standards. The resulting phase information is translated into I and Q differential output voltages that can be connected directly to an RF modulator at the TXOP and TXON pins. The DSP is notified when the transmission is completed. For receiving baseband data, a DSP can program CSP1093's event timing and control register with the exact time to start receiving I and Q samples through TXIP and TXIN pins. When that time is reached, the control portion of the event timing and control register will start the baseband receive section converting I and Q sample pairs. The samples are stored in a double-buffered register until the register contains 32 sample pairs. CSP1093 then notifies the DSP which has ample time to read the information out before the next 32 sample pairs are stored. The voice band ADC converter issues an interrupt to the DSP whenever it finishes converting a 16-bit PCM word. The DSP then reads the new input sample and simultaneously loads the voice band output DAC converter with a new PCM output word. The voice band output can be connected directly to a speaker via AOUTAN and AOUTAP pins and be connected to a Ear-mic speaker via AOUTBN and AOUTBP pins.

#### 8. X-TAL(13MHz)

This system uses the 13MHz TCXO, TCO-9141B, Toyocom. AFC control signal form CSP1093 controls frequency from 13MHz x-tal. It generates the clock frequency. This clock is inverted through NOT gate, TC7S04FU and is connected to CSP1093. 13MHz clock for YMU759 uses a not-inverted clock. Clock for RF parts uses same type.

#### This Document can not be used without Samsung's authorization

#### 9.Camera DSP(LC99704B)

 This chipset is MCP product that combines the CCD Driver with on-chip booster circuit and analogue/digital mixed-signal processing IC.

The booster circuit generate the supply voltages required for CCD drive.

Cameras can use either a +2.8V or +3.0V or +3.3V only power supply system.

The analogue / digital mixed-signal processing IC that integrates the signal-processing functions required in a CCD digital camera and a rich set of additional functions on a single chip. Although the CDS(correlated dual sampling) and AGC circuit required for analog processing and the clamp circuit required for A/D conversion are normally povided on circuits, as well as an A/D converter, on a single chip.

Additionally, it also includes the pulse generator circuits required for CCD drive, the logic circuits for the electronics iris, and the digital signal-processing circuits required to create the digital YUV signal output. This device can take advantage of the features of these digital signal-processing functions to provide auto white balance, automatic dropout detection and correction, mirror image output, and a single line of memory to provide flexibility in the external interface.

This device assumes an internal master clock frequency in the range  $16 \sim 27$  MHz. Normally , either an external clock with that frequency is provided, or else a master clock oscillator circuit is constructed using the built-in oscillator inverter circuit.

And this is also possible to control the CCD drive internal and enternal.

#### 10. Camera ASIC(SSH 275)

This ASIC interfaces between CCD and LCD, and this chip compresses and expands input pictures from CCD with JPEG format.

- CCD I/F: YUV422(16 bit) format, CIF fixed size.
   System clock providing CCD module (13.5 MHz) and Dot clock providing CCD module (13.5 MHz).
- CPU I/F: Accessible to JPEG controller, a control register including, JPEG code buffer, and a thumbnail picture buffer.

Direct access to LCD controller by switching buses.

- LCD I/F: Support LCD controller.

Accessible by switching 2 masters of the Host CPU or ASIC picture processing .


Output format from ASIC is RGB565.

- I2C I/F: I2C master for CCD module control equipped.
  - CCD module is accessible from CPU wiithout paying attention to I2C, as in the case of a normal register write/read.
- JPEG codec : YUV422 picture data is compressed to JPEG code, and JPEG code data is expanded to YUV422 picture data.
- Clock system: As for ASIC, 27 MHz clock input from outside is the main clock.
   2-divided 13.5 MHz is used as CCD module main clock output, dot clock output to CCD module, and ASIC inner clock

#### This Document can not be used without Samsung's authorization

## 3. SGH-P100 Exploded View and its Parts list

#### 1. Cellular phone Exploded View



This Document can not be used without Samsung's authorization

#### 2. Cellular phone Parts list

Locat NO	Description	SEC CODE	Remark
1	FOLDER UPPER	GH75-03160A	
2	LCD FPCB	GH07-00358A	
3	MOTOR	3101-001336	
4	SPEAKER	3001-001427	
5	MAIN LCD	GH07-00253A	
6	FOLDER LOWER	GH75-03191A	
7	SCREW	6001-001478	
8	SCREW CAP	GH74-02775A	
9	MAIN WINDOW	GH75-03362A	
10	CAMERA	GH59-00806A	
11	SIDE DECO	GH72-08113A	
12	SIDE DECO	GH72-08113A	
13	KEYPAD	GH75-03148A	
14	MAIN PBA	GH92-01514A	
15	METAL DOME SHEET	GH59-00821A	
16	MIC	GH30-00029A	
17	IF COVER	GH73-02150A	
18	VOLKEY	GH75-03230A	
19	ANTENNA	GH42-00304A	
20	REAR COVER	GH75-03195A	
21	SCREW	6001-001155	
22	BATTERY	GH43-00906A	

#### 3. Test Jig (GH80-00001A)



3-1. RF Test Cable (GH39-00182A)



3-2. Test Cable (GH39-00122A)



3-3. Serial Cable



3-4. Power Supply Cable



3-5. DATA CABLE (GH39-00159A)



3-6. TA (GH44-00482A)



This Document can not be used without Samsung's authorization

## 4. SGH-P100 MAIN Electrical Parts List

SEC Code	Design LOC
0404-001172	D1101
0404-001172	D1102
0404-001172	D1103
0406-001083	ZD300
0406-001083	ZD301
0406-001152	ZD302
0501 - 000225	Q400
0504-000168	Q100
0504-001151	U701
0504-001151	U702
0504-001151	U703
0506-001052	U102
0601 - 001547	LED801
0601 - 001547	LED802
0601 - 001547	LED803
0601 - 001547	LED804
0601 - 001547	LED805
0601 - 001547	LED806
0601 - 001547	LED807
0601 - 001547	LED808
0601 - 001547	LED809
0601 - 001547	LED810
0601 - 001547	LED812
0604-001146	LED200
0801 - 000796	U1105
0801 - 000796	U1108
0801 - 000796	U1109
0801-002212	U1110
0801 - 002727	U1107
0801 - 002727	U1111
0801 - 002727	U1112
1009-001010	U802
1109-001274	U500
1203-001720	U1104
1203-002568	U100
1204-001960	U401
1204-001982	U1103

1204-001984	U700
1209-001219	U602
1209-001497	U101
1405-001018	ZD308
1405-001082	ZD201
1405-001082	ZD303
1405-001082	ZD304
1405-001082	ZD305
1405-001082	ZD306
1405-001082	ZD307
1405-001082	ZD401
1405-001082	ZD402
1405-001082	ZD403
1405-001082	ZD405
1405-001082	ZD800
1405-001082	ZD801
1405-001082	ZD802
1405-001093	ZD309
2007-000138	R903
2007-000140	R302
2007 - 000140	R303
2007 - 000140	R304
2007 - 000140	R305
2007 - 000140	R306
2007 - 000140	R310
2007 - 000140	R311
2007-000140	R424
2007 - 000141	R113
2007 - 000141	R407
2007-000141	R420
2007-000144	R701
2007-000146	R404
2007-000148	R1104
2007-000148	R402
2007-000148	R421
2007-000148	R425
2007 - 000157	R300
2007 - 000157	R301

This Document can not be used without Samsung's authorization

2007-000157	R600
2007-000157	R602
2007-000162	R405
2007-000162	R415
2007-000162	R422
2007-000162	R503
2007-000162	R607
2007-000162	R710
2007-000162	R711
2007-000162	R712
2007-000163	R1101
2007-000167	R108
2007-000170	R1103
2007-000170	R601
2007-000171	R1000
2007-000171	R1004
2007-000171	R1009
2007-000171	R1106
2007-000171	R307
2007-000171	R308
2007-000171	R403
2007-000171	R417
2007-000171	R426
2007-000171	R427
2007-000171	R431
2007-000171	R707
2007-000171	R904
2007-000172	R104
2007-000172	R1114
2007-000172	R200
2007-000172	R502
2007-000172	R606
2007-000172	R901
2007-000566	R309
2007-000758	R107
2007-000982	R1100
2007-001119	R409
2007-001284	R400
	_

2007-001301         R1105           2007-001305         R1110           2007-001308         R902           2007-001319         R103           2007-001325         R412           2007-002797         R900           2007-003010         R806           2007-003010         R807           2007-003010         R808           2007-003010         R809           2007-003010         R810           2007-003010         R811           2007-003010         R812           2007-003010         R813           2007-003010         R814           2007-003010         R815           2007-003010         R816           2007-007107         R1008           2007-007142         R111           2007-007142         R603           2007-007200         R705           2007-007306         R1109           2007-007306         R1111           2007-007306         R1111           2007-007308         R604           2007-007308         R605           2203-000233         C113           2203-000233         C239		1
2007-001305         R1110           2007-001308         R902           2007-001319         R103           2007-001325         R412           2007-002797         R900           2007-003010         R806           2007-003010         R807           2007-003010         R808           2007-003010         R809           2007-003010         R810           2007-003010         R811           2007-003010         R812           2007-003010         R813           2007-003010         R814           2007-003010         R815           2007-003010         R816           2007-007107         R1008           2007-007142         R111           2007-007142         R603           2007-007200         R705           2007-007200         R706           2007-007306         R1111           2007-007306         R1111           2007-007308         R604           2007-007308         R605           2203-000233         C113           2203-000233         C239	2007-001284	R401
2007-001308         R902           2007-001319         R103           2007-001325         R412           2007-002797         R900           2007-003010         R806           2007-003010         R807           2007-003010         R808           2007-003010         R809           2007-003010         R810           2007-003010         R811           2007-003010         R812           2007-003010         R813           2007-003010         R814           2007-003010         R815           2007-003010         R816           2007-007107         R1008           2007-007142         R111           2007-007142         R111           2007-007200         R705           2007-007200         R706           2007-007306         R1111           2007-007306         R1111           2007-007308         R604           2007-007308         R605           2203-000233         C113           2203-000233         C239	2007-001301	R1105
2007-001319       R406         2007-001325       R412         2007-001333       R423         2007-002797       R900         2007-003010       R806         2007-003010       R807         2007-003010       R808         2007-003010       R810         2007-003010       R811         2007-003010       R812         2007-003010       R813         2007-003010       R814         2007-003010       R815         2007-007107       R1008         2007-007139       R112         2007-007142       R111         2007-007200       R705         2007-007200       R706         2007-007306       R1111         2007-007306       R1112         2007-007306       R1113         2007-007308       R604         2007-007308       R605         2203-000233       C113         2203-000233       C239	2007 - 001305	R1110
2007-001319       R406         2007-001325       R412         2007-001333       R423         2007-003010       R806         2007-003010       R807         2007-003010       R808         2007-003010       R809         2007-003010       R810         2007-003010       R811         2007-003010       R812         2007-003010       R813         2007-003010       R815         2007-003010       R816         2007-007107       R1008         2007-007139       R112         2007-007142       R111         2007-007200       R706         2007-007200       R706         2007-007306       R1111         2007-007306       R1112         2007-007308       R604         2007-007308       R605         2203-000233       C239	2007-001308	R902
2007-001325       R412         2007-001333       R423         2007-002797       R900         2007-003010       R806         2007-003010       R807         2007-003010       R808         2007-003010       R810         2007-003010       R811         2007-003010       R812         2007-003010       R813         2007-003010       R814         2007-003010       R815         2007-003010       R816         2007-007107       R1008         2007-007142       R111         2007-007142       R603         2007-007200       R706         2007-007200       R706         2007-007306       R1109         2007-007306       R1111         2007-007306       R1113         2007-007308       R604         2007-007308       R605         2203-000233       C239	2007-001319	R103
2007-001333       R423         2007-002797       R900         2007-003010       R806         2007-003010       R807         2007-003010       R808         2007-003010       R810         2007-003010       R811         2007-003010       R812         2007-003010       R813         2007-003010       R814         2007-003010       R815         2007-007107       R1008         2007-007139       R112         2007-007142       R111         2007-007200       R106         2007-007200       R705         2007-007306       R1109         2007-007306       R1111         2007-007306       R1112         2007-007308       R604         2007-007308       R605         2203-000233       C113         2203-000233       C239	2007-001319	R406
2007-002797         R900           2007-003010         R806           2007-003010         R807           2007-003010         R808           2007-003010         R810           2007-003010         R811           2007-003010         R812           2007-003010         R813           2007-003010         R814           2007-003010         R816           2007-007107         R1008           2007-007142         R111           2007-007142         R111           2007-007200         R106           2007-007200         R705           2007-007306         R1109           2007-007306         R1111           2007-007306         R1112           2007-007308         R604           2007-007308         R605           2203-000233         C113           2203-000233         C239	2007-001325	R412
2007-003010       R807         2007-003010       R808         2007-003010       R808         2007-003010       R810         2007-003010       R811         2007-003010       R812         2007-003010       R813         2007-003010       R814         2007-003010       R815         2007-003010       R816         2007-007107       R1008         2007-007139       R112         2007-007142       R111         2007-007200       R106         2007-007200       R705         2007-007306       R1109         2007-007306       R1111         2007-007306       R1112         2007-007308       R604         2007-007308       R605         2203-000233       C113         2203-000233       C239	2007-001333	R423
2007-003010       R808         2007-003010       R808         2007-003010       R809         2007-003010       R810         2007-003010       R811         2007-003010       R813         2007-003010       R814         2007-003010       R816         2007-007107       R1008         2007-007139       R112         2007-007142       R111         2007-007200       R106         2007-007200       R705         2007-007306       R1109         2007-007306       R1111         2007-007306       R1112         2007-007308       R604         2007-007308       R605         2203-000233       C113         2203-000233       C239	2007 - 002797	R900
2007-003010       R809         2007-003010       R809         2007-003010       R810         2007-003010       R811         2007-003010       R812         2007-003010       R813         2007-003010       R815         2007-003010       R816         2007-007107       R1008         2007-007139       R112         2007-007142       R111         2007-007142       R603         2007-007200       R706         2007-007200       R706         2007-007306       R1109         2007-007306       R1111         2007-007308       R604         2007-007308       R605         2203-000233       C113         2203-000233       C239	2007-003010	R806
2007-003010       R809         2007-003010       R810         2007-003010       R811         2007-003010       R812         2007-003010       R813         2007-003010       R814         2007-003010       R816         2007-007107       R1008         2007-007139       R112         2007-007142       R111         2007-007200       R106         2007-007200       R705         2007-007306       R1109         2007-007306       R1111         2007-007306       R1112         2007-007308       R604         2007-007308       R605         2203-000233       C239	2007-003010	R807
2007-003010       R811         2007-003010       R812         2007-003010       R813         2007-003010       R814         2007-003010       R815         2007-003010       R816         2007-007107       R1008         2007-007139       R112         2007-007142       R111         2007-007200       R106         2007-007200       R705         2007-007306       R1109         2007-007306       R1111         2007-007306       R1112         2007-007308       R604         2007-007308       R605         2203-000233       C113         2203-000233       C239	2007-003010	R808
2007-003010       R811         2007-003010       R812         2007-003010       R813         2007-003010       R814         2007-003010       R815         2007-007107       R1008         2007-007139       R112         2007-007142       R111         2007-007200       R106         2007-007200       R705         2007-007306       R1109         2007-007306       R1111         2007-007306       R1112         2007-007308       R604         2007-007308       R605         2203-000233       C239	2007-003010	R809
2007-003010       R813         2007-003010       R814         2007-003010       R815         2007-003010       R816         2007-007107       R1008         2007-007139       R112         2007-007142       R111         2007-007142       R603         2007-007200       R706         2007-007200       R706         2007-007306       R1109         2007-007306       R1111         2007-007306       R1112         2007-007308       R604         2007-007308       R605         2203-000233       C113         2203-000233       C239	2007-003010	R810
2007-003010       R813         2007-003010       R814         2007-003010       R815         2007-007107       R1008         2007-007139       R112         2007-007142       R111         2007-007200       R106         2007-007200       R705         2007-007306       R1109         2007-007306       R1111         2007-007306       R1112         2007-007306       R1113         2007-007308       R604         2007-007308       R605         2203-000233       C113         2203-000233       C239	2007-003010	R811
2007-003010       R814         2007-003010       R815         2007-007107       R1008         2007-007139       R112         2007-007142       R111         2007-007142       R603         2007-007200       R106         2007-007200       R705         2007-007306       R1109         2007-007306       R1111         2007-007306       R1112         2007-007308       R604         2007-007308       R605         2203-000233       C113         2203-000233       C239	2007-003010	R812
2007-003010       R815         2007-003010       R816         2007-007107       R1008         2007-007139       R112         2007-007142       R111         2007-007200       R106         2007-007200       R705         2007-007200       R706         2007-007306       R1109         2007-007306       R1111         2007-007306       R1112         2007-007308       R604         2007-007308       R605         2203-000233       C113         2203-000233       C239	2007-003010	R813
2007-003010       R816         2007-007107       R1008         2007-007139       R112         2007-007142       R111         2007-007142       R603         2007-007200       R106         2007-007200       R705         2007-007306       R1109         2007-007306       R1111         2007-007306       R1112         2007-007308       R604         2007-007308       R605         2203-000233       C113         2203-000233       C239	2007-003010	R814
2007-007107       R1008         2007-007139       R112         2007-007142       R111         2007-007200       R106         2007-007200       R705         2007-007200       R706         2007-007306       R1109         2007-007306       R1111         2007-007306       R1112         2007-007308       R604         2007-007308       R605         2203-000233       C113         2203-000233       C239	2007-003010	R815
2007-007139       R112         2007-007142       R111         2007-007142       R603         2007-007200       R106         2007-007200       R705         2007-007300       R109         2007-007306       R1111         2007-007306       R1112         2007-007308       R604         2007-007308       R605         2203-000233       C113         2203-000233       C239	2007-003010	R816
2007-007142 R111 2007-007142 R603 2007-007200 R106 2007-007200 R705 2007-007200 R706 2007-007306 R1109 2007-007306 R1111 2007-007306 R1112 2007-007306 R1113 2007-007308 R604 2007-007308 R605 2203-000233 C113 2203-000233 C239	2007-007107	R1008
2007-007142       R603         2007-007200       R106         2007-007200       R705         2007-007300       R706         2007-007306       R1109         2007-007306       R1111         2007-007306       R1112         2007-007308       R604         2007-007308       R605         2203-000233       C113         2203-000233       C239	2007-007139	R112
2007-007200       R106         2007-007200       R705         2007-007200       R706         2007-007306       R1109         2007-007306       R1111         2007-007306       R1112         2007-007308       R604         2007-007308       R605         2203-000233       C113         2203-000233       C239	2007-007142	R111
2007-007200 R705 2007-007200 R706 2007-007306 R1109 2007-007306 R1111 2007-007306 R1112 2007-007306 R1113 2007-007308 R604 2007-007308 R605 2203-000233 C113 2203-000233 C239	2007-007142	R603
2007-007200 R706 2007-007306 R1109 2007-007306 R1111 2007-007306 R1112 2007-007306 R1113 2007-007308 R604 2007-007308 R605 2203-000233 C113 2203-000233 C239	2007-007200	R106
2007-007306 R1109 2007-007306 R1111 2007-007306 R1112 2007-007306 R1113 2007-007308 R604 2007-007308 R605 2203-000233 C113 2203-000233 C239	2007-007200	R705
2007-007306 R1111 2007-007306 R1112 2007-007306 R1113 2007-007308 R604 2007-007308 R605 2203-000233 C113 2203-000233 C239	2007-007200	R706
2007-007306 R1112 2007-007306 R1113 2007-007308 R604 2007-007308 R605 2203-000233 C113 2203-000233 C239	2007-007306	R1109
2007-007306 R1113 2007-007308 R604 2007-007308 R605 2203-000233 C113 2203-000233 C239	2007-007306	R1111
2007-007308 R604 2007-007308 R605 2203-000233 C113 2203-000233 C239	2007-007306	R1112
2007-007308 R605 2203-000233 C113 2203-000233 C239	2007 - 007306	R1113
2203-000233 C113 2203-000233 C239	2007-007308	R604
2203-000233 C239	2007-007308	R605
	2203-000233	C113
	2203-000233	C239
2203-000233 C615	2203-000233	C615
2203-000233 C700	2203-000233	C700
2203-000233 C902	2203-000233	C902

This Document can not be used without Samsung's authorization

2203-000233	C904
2203-000233	C905
2203-000233	C906
2203-000233	C907
2203-000254	C107
2203-000254	C1100
2203-000254	C1102
2203-000254	C1105
2203-000254	C1108
2203-000254	C1123
2203-000254	C1126
2203-000254	C1127
2203-000254	C1128
2203-000254	C1129
2203-000254	C1130
2203-000254	C1131
2203-000254	C1132
2203-000254	C1133
2203-000254	C1136
2203-000254	C1138
2203-000254	C205
2203-000254	C504
2203-000254	C601
2203-000254	C602
2203-000254	C603
2203-000254	C604
2203-000254	C608
2203-000254	C610
2203-000254	C611
2203-000254	C612
2203-000254	C613
2203-000254	C617
2203-000254	C706
2203-000254	C707
2203-000254	C708
2203-000254	C709
2203-000254	C710
2203-000254	C711

2203-000254         C712           2203-000254         C713           2203-000254         C911           2203-000254         C912           2203-000254         C914           2203-000278         C415           2203-000359         C406           2203-000386         C909           2203-000438         C202           2203-000438         C222           2203-000438         C411           2203-000438         C413           2203-000438         C413           2203-000438         C414           2203-000438         C414           2203-000585         C1137           2203-000628         C614           2203-000628         C616           2203-000629         C430           2203-000612         C100           2203-000812         C1012           2203-000812         C1015           2203-000812         C1016           2203-000812         C104           2203-000812         C210           2203-000812         C210           2203-000812         C217           2203-000812         C217           2203-000812         C701		
2203-000254         C912           2203-000254         C913           2203-000254         C914           2203-000278         C415           2203-000359         C406           2203-000386         C909           2203-000438         C202           2203-000438         C222           2203-000438         C243           2203-000438         C411           2203-000438         C413           2203-000438         C413           2203-000438         C414           2203-000585         C1137           2203-000585         C407           2203-000628         C614           2203-000679         C430           2203-000812         C1012           2203-000812         C1015           2203-000812         C1016           2203-000812         C104           2203-000812         C105           2203-000812         C210           2203-000812         C217           2203-000812         C217           2203-000812         C701           2203-000812         C701           2203-000812         C701           2203-000812         C715	2203-000254	C712
2203-000254         C912           2203-000254         C913           2203-000278         C415           2203-000278         C900           2203-000359         C406           2203-000386         C909           2203-000438         C1014           2203-000438         C202           2203-000438         C222           2203-000438         C411           2203-000438         C413           2203-000438         C413           2203-000585         C1137           2203-000585         C407           2203-000628         C614           2203-000628         C616           2203-000679         C430           2203-000812         C1012           2203-000812         C1015           2203-000812         C104           2203-000812         C104           2203-000812         C105           2203-000812         C210           2203-000812         C217           2203-000812         C217           2203-000812         C701           2203-000812         C701           2203-000812         C701           2203-000812         C715	2203-000254	C713
2203-000254         C914           2203-000278         C415           2203-000278         C900           2203-000359         C406           2203-000438         C909           2203-000438         C202           2203-000438         C222           2203-000438         C243           2203-000438         C411           2203-000438         C413           2203-000438         C413           2203-000585         C1137           2203-000585         C407           2203-000628         C614           2203-000628         C616           2203-000679         C430           2203-000812         C100           2203-000812         C1015           2203-000812         C1016           2203-000812         C104           2203-000812         C105           2203-000812         C210           2203-000812         C217           2203-000812         C217           2203-000812         C701           2203-000812         C701           2203-000812         C701           2203-000812         C701           2203-000812         C715	2203-000254	C911
2203-000254         C914           2203-000278         C415           2203-000359         C406           2203-000386         C909           2203-000438         C1014           2203-000438         C202           2203-000438         C243           2203-000438         C411           2203-000438         C413           2203-000438         C414           2203-000585         C1137           2203-000585         C407           2203-000628         C614           2203-000679         C430           2203-000679         C430           2203-000812         C100           2203-000812         C1012           2203-000812         C1015           2203-000812         C104           2203-000812         C105           2203-000812         C210           2203-000812         C210           2203-000812         C422           2203-000812         C701           2203-000812         C701           2203-000812         C701           2203-000812         C714           2203-000812         C715	2203-000254	C912
2203-000278         C415           2203-000278         C900           2203-000359         C406           2203-000438         C909           2203-000438         C202           2203-000438         C222           2203-000438         C411           2203-000438         C413           2203-000438         C414           2203-000585         C1137           2203-000585         C407           2203-000628         C614           2203-000679         C430           2203-000679         C606           2203-000812         C1012           2203-000812         C1015           2203-000812         C104           2203-000812         C105           2203-000812         C210           2203-000812         C210           2203-000812         C221           2203-000812         C422           2203-000812         C701           2203-000812         C701           2203-000812         C701           2203-000812         C714           2203-000812         C715	2203-000254	C913
2203-000278         C900           2203-000359         C406           2203-000438         C909           2203-000438         C1014           2203-000438         C202           2203-000438         C243           2203-000438         C411           2203-000438         C413           2203-000438         C414           2203-000585         C1137           2203-000585         C407           2203-000628         C614           2203-000679         C430           2203-000679         C606           2203-000812         C1012           2203-000812         C1015           2203-000812         C104           2203-000812         C105           2203-000812         C210           2203-000812         C217           2203-000812         C221           2203-000812         C701           2203-000812         C701           2203-000812         C701           2203-000812         C701           2203-000812         C714           2203-000812         C715	2203-000254	C914
2203-000359         C406           2203-000386         C909           2203-000438         C1014           2203-000438         C202           2203-000438         C243           2203-000438         C411           2203-000438         C413           2203-000438         C414           2203-000585         C1137           2203-000585         C407           2203-000628         C614           2203-000679         C430           2203-000679         C606           2203-000812         C1012           2203-000812         C1015           2203-000812         C104           2203-000812         C105           2203-000812         C210           2203-000812         C217           2203-000812         C221           2203-000812         C221           2203-000812         C701           2203-000812         C701           2203-000812         C701           2203-000812         C714           2203-000812         C715	2203-000278	C415
2203-000386         C909           2203-000438         C1014           2203-000438         C202           2203-000438         C222           2203-000438         C411           2203-000438         C413           2203-000438         C414           2203-000585         C1137           2203-000585         C407           2203-000628         C616           2203-000679         C430           2203-000812         C100           2203-000812         C1012           2203-000812         C1015           2203-000812         C104           2203-000812         C105           2203-000812         C210           2203-000812         C217           2203-000812         C217           2203-000812         C217           2203-000812         C422           2203-000812         C701           2203-000812         C701           2203-000812         C714           2203-000812         C715	2203-000278	C900
2203-000438         C1014           2203-000438         C202           2203-000438         C222           2203-000438         C411           2203-000438         C413           2203-000438         C414           2203-000585         C1137           2203-000628         C614           2203-000628         C616           2203-000679         C430           2203-000812         C100           2203-000812         C1012           2203-000812         C1015           2203-000812         C104           2203-000812         C105           2203-000812         C210           2203-000812         C217           2203-000812         C217           2203-000812         C217           2203-000812         C217           2203-000812         C701           2203-000812         C701           2203-000812         C702           2203-000812         C714           2203-000812         C715	2203-000359	C406
2203-000438         C202           2203-000438         C222           2203-000438         C243           2203-000438         C411           2203-000438         C413           2203-000585         C1137           2203-000585         C407           2203-000628         C614           2203-000628         C616           2203-000679         C430           2203-000812         C100           2203-000812         C1012           2203-000812         C1015           2203-000812         C104           2203-000812         C104           2203-000812         C210           2203-000812         C217           2203-000812         C217           2203-000812         C221           2203-000812         C422           2203-000812         C701           2203-000812         C702           2203-000812         C714           2203-000812         C715	2203-000386	C909
2203-000438         C222           2203-000438         C243           2203-000438         C411           2203-000438         C413           2203-000585         C1137           2203-000585         C407           2203-000628         C614           2203-000679         C430           2203-000679         C606           2203-000812         C1012           2203-000812         C1015           2203-000812         C104           2203-000812         C104           2203-000812         C105           2203-000812         C210           2203-000812         C217           2203-000812         C221           2203-000812         C422           2203-000812         C701           2203-000812         C702           2203-000812         C714           2203-000812         C715	2203-000438	C1014
2203-000438       C243         2203-000438       C411         2203-000438       C413         2203-000585       C1137         2203-000585       C407         2203-000628       C614         2203-000679       C430         2203-000679       C606         2203-000812       C1012         2203-000812       C1015         2203-000812       C104         2203-000812       C104         2203-000812       C105         2203-000812       C210         2203-000812       C217         2203-000812       C217         2203-000812       C422         2203-000812       C701         2203-000812       C702         2203-000812       C714         2203-000812       C715	2203-000438	C202
2203-000438       C413         2203-000438       C414         2203-000585       C1137         2203-000585       C407         2203-000628       C614         2203-000628       C616         2203-000679       C430         2203-000812       C100         2203-000812       C1012         2203-000812       C1015         2203-000812       C104         2203-000812       C105         2203-000812       C210         2203-000812       C217         2203-000812       C2217         2203-000812       C422         2203-000812       C701         2203-000812       C701         2203-000812       C702         2203-000812       C714         2203-000812       C715	2203-000438	C222
2203-000438       C414         2203-000585       C1137         2203-000585       C407         2203-000628       C614         2203-000679       C430         2203-000679       C606         2203-000812       C100         2203-000812       C1012         2203-000812       C1015         2203-000812       C104         2203-000812       C105         2203-000812       C210         2203-000812       C217         2203-000812       C221         2203-000812       C422         2203-000812       C701         2203-000812       C701         2203-000812       C714         2203-000812       C714         2203-000812       C715	2203-000438	C243
2203-000438       C414         2203-000585       C1137         2203-000628       C614         2203-000628       C616         2203-000679       C430         2203-000679       C606         2203-000812       C100         2203-000812       C1012         2203-000812       C1015         2203-000812       C104         2203-000812       C105         2203-000812       C210         2203-000812       C217         2203-000812       C231         2203-000812       C422         2203-000812       C701         2203-000812       C702         2203-000812       C714         2203-000812       C715	2203-000438	C411
2203-000585       C1137         2203-000628       C614         2203-000628       C616         2203-000679       C430         2203-000679       C606         2203-000812       C100         2203-000812       C1012         2203-000812       C1015         2203-000812       C104         2203-000812       C105         2203-000812       C210         2203-000812       C217         2203-000812       C217         2203-000812       C422         2203-000812       C701         2203-000812       C702         2203-000812       C714         2203-000812       C715	2203-000438	C413
2203-000585       C407         2203-000628       C614         2203-000679       C430         2203-000679       C606         2203-000812       C100         2203-000812       C1012         2203-000812       C1015         2203-000812       C104         2203-000812       C105         2203-000812       C210         2203-000812       C217         2203-000812       C231         2203-000812       C422         2203-000812       C701         2203-000812       C702         2203-000812       C714         2203-000812       C715	2203-000438	C414
2203-000628       C614         2203-000679       C430         2203-000679       C606         2203-000812       C100         2203-000812       C1012         2203-000812       C1015         2203-000812       C104         2203-000812       C104         2203-000812       C210         2203-000812       C217         2203-000812       C231         2203-000812       C422         2203-000812       C701         2203-000812       C702         2203-000812       C714         2203-000812       C715	2203-000585	C1137
2203-000628       C616         2203-000679       C430         2203-000812       C100         2203-000812       C1012         2203-000812       C1015         2203-000812       C1016         2203-000812       C104         2203-000812       C210         2203-000812       C217         2203-000812       C231         2203-000812       C422         2203-000812       C701         2203-000812       C702         2203-000812       C714         2203-000812       C715	2203-000585	C407
2203-000679       C430         2203-000679       C606         2203-000812       C100         2203-000812       C1012         2203-000812       C1015         2203-000812       C104         2203-000812       C105         2203-000812       C210         2203-000812       C217         2203-000812       C231         2203-000812       C422         2203-000812       C701         2203-000812       C702         2203-000812       C714         2203-000812       C715	2203-000628	C614
2203-000679       C606         2203-000812       C100         2203-000812       C1012         2203-000812       C1015         2203-000812       C104         2203-000812       C105         2203-000812       C210         2203-000812       C217         2203-000812       C231         2203-000812       C422         2203-000812       C701         2203-000812       C702         2203-000812       C714         2203-000812       C715	2203-000628	C616
2203-000812       C100         2203-000812       C1012         2203-000812       C1015         2203-000812       C104         2203-000812       C105         2203-000812       C210         2203-000812       C217         2203-000812       C231         2203-000812       C422         2203-000812       C701         2203-000812       C702         2203-000812       C714         2203-000812       C715	2203-000679	C430
2203-000812 C1012 2203-000812 C1015 2203-000812 C1016 2203-000812 C104 2203-000812 C105 2203-000812 C210 2203-000812 C217 2203-000812 C231 2203-000812 C422 2203-000812 C701 2203-000812 C702 2203-000812 C714 2203-000812 C715	2203-000679	C606
2203-000812 C1015 2203-000812 C1016 2203-000812 C104 2203-000812 C105 2203-000812 C210 2203-000812 C217 2203-000812 C231 2203-000812 C422 2203-000812 C701 2203-000812 C701 2203-000812 C702 2203-000812 C714 2203-000812 C715	2203-000812	C100
2203-000812       C1016         2203-000812       C104         2203-000812       C105         2203-000812       C210         2203-000812       C217         2203-000812       C231         2203-000812       C422         2203-000812       C701         2203-000812       C702         2203-000812       C714         2203-000812       C715	2203-000812	C1012
2203-000812 C104 2203-000812 C105 2203-000812 C210 2203-000812 C217 2203-000812 C231 2203-000812 C422 2203-000812 C701 2203-000812 C702 2203-000812 C714 2203-000812 C715	2203-000812	C1015
2203-000812 C105 2203-000812 C210 2203-000812 C217 2203-000812 C231 2203-000812 C422 2203-000812 C701 2203-000812 C702 2203-000812 C714 2203-000812 C715	2203-000812	C1016
2203-000812 C210 2203-000812 C217 2203-000812 C231 2203-000812 C422 2203-000812 C701 2203-000812 C702 2203-000812 C714 2203-000812 C715	2203-000812	C104
2203-000812 C217 2203-000812 C231 2203-000812 C422 2203-000812 C701 2203-000812 C702 2203-000812 C714 2203-000812 C715	2203-000812	C105
2203-000812 C231 2203-000812 C422 2203-000812 C701 2203-000812 C702 2203-000812 C714 2203-000812 C715	2203-000812	C210
2203-000812 C422 2203-000812 C701 2203-000812 C702 2203-000812 C714 2203-000812 C715	2203-000812	C217
2203-000812 C701 2203-000812 C702 2203-000812 C714 2203-000812 C715	2203-000812	C231
2203-000812 C702 2203-000812 C714 2203-000812 C715	2203-000812	C422
2203-000812 C714 2203-000812 C715	2203-000812	C701
2203-000812 C715	2203-000812	C702
	2203-000812	C714
2203-000812 C716	2203-000812	C715
	2203-000812	C716

This Document can not be used without Samsung's authorization

<b>-</b>	
2203-000812	C901
2203-000854	C420
2203-000854	C424
2203-000940	C1143
2203-000995	C1000
2203-001124	C1139
2203-001124	C1140
2203-001124	C1141
2203-001124	C1142
2203-001259	C432
2203-001405	C607
2203-001412	C910
2203-001598	C102
2203-001598	C109
2203-001598	C110
2203-001598	C111
2203-001598	C112
2203-001598	C114
2203-001598	C115
2203-001598	C118
2203-001598	C119
2203-002677	C1005
2203-002677	C1006
2203-002687	C401
2203-005061	C101
2203-005061	C103
2203-005061	C1103
2203-005061	C1104
2203-005061	C1109
2203-005061	C1110
2203-005061	C1111
2203-005061	C1112
2203-005061	C1113
2203-005061	C1114
2203-005061	C1115
2203-005061	C1117
2203-005061	C1118
2203-005061	C1119

2203-005061	C1120
2203-005061	C1121
2203-005061	C1122
2203-005061	C1124
2203-005061	C1125
2203-005061	C120
2203-005061	C402
2203-005061	C408
2203-005061	C412
2203-005061	C417
2203-005061	C500
2203-005061	C501
2203-005061	C502
2203-005061	C605
2203-005061	C705
2203-005065	C1135
2203-005065	C232
2203-005065	C233
2203-005065	C400
2203-005065	C416
2203-005065	C704
2203-005234	C1001
2203-005234	C1009
2203-005234	C1010
2203-005288	C1003
2203-005288	C1004
2203-005481	C1116
2203-005482	C200
2203-005482	C811
2203-005483	C106
2203-005496	C1101
2203-005496	C403
2203-005496	C600
2203-005496	C609
2203-005496	C703
2203-005496	C903
2203-005503	C1144
2203-005509	C201

This Document can not be used without Samsung's authorization

2404-001086	C425	1001-001250
2404-001100	C1106	1203-003045
2404-001100	C1107	2703-002636
2404-001100	C1134	1201-002042
2404-001105	C125	2909-001208
2404-001134	C1013	1205-002384
2404-001151	C409	GH09-00023A
2404-001268	C126	GH13-00012A
2404-001268	C404	
2503-001041	C207	
2503-001041	C208	
2503-001053	C203	
2503-001053	C204	
2503-001053	C206	
2503-001053	C211	
2503-001053	C212	
2503-001053	C213	
2703-001733	L1003	
2703-001949	L1000	
2703-002176	L1017	
2703-002207	L900	
2703-002367	L1010	
2703-002367	L1012	
2703-002485	L1001	
2703-002544	L1002	
2801-003747	OSC601	
2804-001492	U1102	
2809-001266	OSC901	
2904-001410	F1003	
3404-001152	VOL_DN	
3404-001152	VOL_UP	
3705-001287	CON1	
3709-001244	CN100	
3711-005078	CN201	
3711-005225	CN1101	
3722-001715	CN401	
4302-001130	M101	
3710-002012	CN300	
·		


1001-001250	U400
1203-003045	U1106
2703-002636	L1006
1201-002042	U1000
2909-001208	U1001
1205-002384	U900
GH09-00023A	U601
GH13-00012A	U1101

This Document can not be used without Samsung's authorization


MEMO

## 5. SGH-P100 Block Diagrams

#### 1. RF Solution Block Diagram




#### 2. Base Band Solution Block Diagram




## 6. SGH-P100 PCB Diagrams

#### 1. Main PCB Top Diagram




#### 2. Main PCB Bottom Diagram




## 7. SGH-P100 Flow Chart of Troubleshooting


#### 1. Power On




#### 2. Initial




#### 3. Sim Part




#### 4. Charging Part







This Document can not be used without Samsung's authorization

#### 5. Microphone Part




#### 6. Speaker Part






This Document can not be used without Samsung's authorization


#### 7. Camera part




#### 8. EGSM Receiver




#### 9. EGSM transmitter



#### 10. DCS Receiver



#### 11. PCS Receiver



#### 12. DCS/PCS transmitter

